



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Fuel tank	-	-	-	gr	GU191002551	1	
2	Decal set	-	-	-	-	GU19923300	1	
3	Decal "Moto Guzzi"	-	-	-	-	GU14917300	2	
4	Clip	-	-	-	-	GU14105100	8	
5	RH fuel cock	-	-	-	-	GU65105400	1	
6	LH fuel cock	-	-	-	-	GU65105401	1	
7	Tie rod	-	-	-	-	GU19102750	1	
8	Front mudguard	-	-	-	gr	GU194343001	1	
9	Rubber spacer	-	-	-	-	GU19659700	2	
10	Eyelet	-	-	-	-	GU19436500	1	
11	Spring washer 8x15x0,3	-	-	-	-	GU61270300	4	
12	Nut M8X1,25	-	-	-	-	GU92602208	4	
13	Splash guard	-	-	-	-	GU19438700	1	
14	Hex screw M6X20	-	-	-	-	GU98054320	2	
15	Rubber spacer	-	-	-	-	GU93110060	8	
16	Washer	-	-	-	-	GU95000206	4	
17	Washer 6,4x12x1,2	-	-	-	-	GU95100141	4	
18	Nut M6x1	-	-	-	-	GU92630106	4	
19	Drift	-	-	-	-	GU19705900	2	
20	Rear mudguard	-	-	-	gr	GU194370201	1	
21	Fairlead	-	-	-	-	GU91551102	1	
22	Screw	-	-	-	-	GU98054312	2	
23	Washer 6,15x11x0,8	-	-	-	-	GU95004206	2	
24	Washer 5,3x10x0,5	-	-	-	-	GU95100121	4	
25	Nut	-	-	-	-	GU92602206	4	
26	Wiring harness support	-	-	-	-	GU19438500	1	
27	Number plate holder	-	-	-	-	GU01474630	1	
28	Screw	-	-	-	-	GU98200408	4	
29	Washer	-	-	-	-	GU95000204	4	
30	Washer	-	-	-	-	GU95129080	4	
31	Nut	-	-	-	-	GU92602204	4	
32	RH body panel blank	-	-	-	gr	GU194762501	1	
33	LH body panel blank	-	-	-	gr	GU194763501	1	

34	Net panel (r)	-	-	-	-	-	GU19478150	1
35	Net panel (l)	-	-	-	-	-	GU19478250	1
36	Plate	-	-	-	-	-	GU39922200	6
37	Rubber spacer	-	-	-	-	-	GU19478550	2
38	Rubber spacer	-	-	-	-	-	GU19478750	4
39	"V35" finish	-	-	-	V35	-	GU19922000	2
	Name plate "V50"	-	-	-	V50	-	GU19922051	2
40	Saddle	-	-	-	-	-	GU19460505	1
41	Rubber spacer	-	-	-	-	-	GU19461650	4
42	Pillion grab bar	-	-	-	-	-	GU19464350	1
43	Hex screw M8X20	-	-	-	-	-	GU98054420	2
44	Spring washer 8x15x0,3	-	-	-	-	-	GU61270300	2
45	Nut	-	-	-	-	-	GU92630108	2
46	Taillight body	-	-	-	-	-	GU19741000	1
47	Support	-	-	-	-	-	GU19741200	1
48	Screw	-	-	-	-	-	GU98054314	2
49	Washer 5,3x10x0,5	-	-	-	-	-	GU95100121	4
50	Net panel (r)	-	-	-	-	-	GU19925000	1
51	Net panel (l)	-	-	-	-	-	GU19925100	1
52	Special cap screw M5x10	-	-	-	-	-	GU98290511	2
53	Fuel filler cap	-	-	-	-	-	GU19103950	1
54	Tank door lock	-	-	-	-	-	GU19105052	1


		V 35 - V 50 ACC. ELETTRONICA 350-500 1977-1980	GU074	00	TAB N.	02		
BEVEL GEAR								
								
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Transmission box, blank	-	-	-	-	GU19350322	1	
2	Clearance washer	-	-	-	-	GU19351900	1	
3	Gasket ring 35x47x7	-	-	-	-	GU90403547	1	
4	Clearance washer	-	-	-	-	GU19351100	1	
5	Roller bearing 35x50x17	-	-	-	-	GU92252235	1	
6	Oil plug	-	-	-	-	GU12022600	1	
7	O-ring 20,24X2,62	-	-	-	-	GU90706203	1	
8	Oil level plug	-	-	-	-	GU95980214	1	
9	Gasket	-	-	-	-	GU10528900	1	
10	Breather plug	-	-	-	-	GU19206501	1	
11	Gasket	-	-	-	-	GU10528900	1	
12	Stud bolt 8x46	-	-	-	-	GU96508045	4	
13	Cover	-	-	-	-	GU19350421	1	
14	Ball bearing 70x110x13	-	-	-	-	GU92201070	1	
15	Gasket ring 75x90x8	-	-	-	-	GU90407590	1	
16	Pin	-	-	-	-	GU19351401	1	
17	Stop ring	-	-	-	-	GU90353030	1	
18	Bevel gear Z=8/31	-	-	-	-	GU20354621	1	
19	Screw M8X25	-	-	-	-	GU12067701	6	
20	Safety plate	-	-	-	-	GU12356400	3	
21	Spacer 1,2 mm	-	-	-	-	GU19355408	1	
	Spacer 0,8 mm	-	-	-	-	GU19355400	1	
	Spacer 0,9 mm	-	-	-	-	GU19355402	1	
	Spacer 1 mm	-	-	-	-	GU19355404	1	
	Spacer 1,3 mm	-	-	-	-	GU19355410	1	
	Spacer 1,1 mm	-	-	-	-	GU19355406	1	
22	Gasket	-	-	-	-	GU19350700	2	
23	Thrust washer	-	-	-	-	GU19352300	1	
24	Thrust washer	-	-	-	-	GU19353500	1	
25	Screw M8X25	-	-	-	-	GU98054425	7	
26	Spring washer 8x15x0,3	-	-	-	-	GU61270300	7	
27	Plate	-	-	-	-	GU95187008	7	
28	Rear brake disc	-	-	-	-	GU19635700	1	

29	Washer 8,4X13X0,8	-	-	-	-	-	GU14615901	6
30	Screw	-	-	-	-	-	GU98054418	6
31	Bearing casing	-	-	-	-	-	GU19352401	1
32	Roller bearing 20x47x14	-	-	-	-	-	GU92249220	2
33	Spacer 1,5 mm	-	-	-	-	-	GU19355305	2
	Spacer 1 mm	-	-	-	-	-	GU19355300	2
	Spacer 1,2 mm	-	-	-	-	-	GU19355302	2
34	Spacer	-	-	-	-	-	GU19355100	1
35	Shim 0,1 mm	-	-	-	-	-	GU19355200	2
36	Shim 0,15 mm	-	-	-	-	-	GU19355202	11
37	Spacer	-	-	-	-	-	GU19356801	1
38	Gasket ring 18,77X1,78	-	-	-	-	-	GU90706188	1
39	Nut	-	-	-	-	-	GU19356700	1
40	Gasket ring	-	-	-	-	-	GU90706552	1
41	Gasket ring	-	-	-	-	-	GU90403247	1
42	Pin	-	-	-	-	-	GU19555200	1
43	Nut M8X1,25	-	-	-	-	-	GU92602208	2

Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Headlight	-	-	-	-	GU28740533	1	
2	Cap	-	-	-	-	GU19740458	1	
3	Light frame	-	-	-	-	GU19740454	1	
4	Optical group	-	-	-	-	GU19740200	1	
5	Lamp 12V 45/40W	-	-	-	-	GU93450231	1	
6	Main switch	-	-	-	-	GU17740364	1	
7	Lamp 12V-4W	-	-	-	-	GU93450119	1	
8	Lampholder	-	-	-	-	GU17740405	1	
9	Screw	-	-	-	-	GU14740355	2	
10	Washer	-	-	-	-	GU14740356	2	
11	Taillight assy	-	-	-	-	GU19740900	1	
12	Taillight	-	-	-	-	GU65740900	1	
13	Lamp 12V/5-21W	-	-	-	-	GU93450224	2	
14	Taillight lens	-	-	-	-	GU65741700	1	
15	Fuse holder box	-	-	-	-	GU19743000	1	
17	Fuse 16A	-	-	-	-	GU17742550	6	
18	Screw	-	-	-	-	GU98202530	2	
19	Washer	-	-	-	-	GU95000205	2	
20	Notched washer	-	-	-	-	GU95021105	2	
21	Nut	-	-	-	-	GU92602205	2	
22	Horn	-	-	-	-	GU14743700	1	
23	Electrical system	-	-	-	-	GU19747100	1	
24	Wiring	-	-	-	-	GU19747300	1	
25	Earth cable	-	-	-	-	GU14748100	1	
26	Taillight wiring harn.	-	-	-	-	GU19747200	1	
27	Connector 12 vie	-	-	-	-	GU19723100	2	
28	Connector 3 vie	-	-	-	-	GU19723000	1	
29	Connector	-	-	-	-	GU19732400	1	
30	Cap	-	-	-	-	GU12735100	1	
31	Connector 4 vie	-	-	-	-	GU17756200	1	
32	Hose clamp 2,4x92	-	-	-	-	GU49609601	2	
33	Connector 4 vie	-	-	-	-	GU17736300	1	
34	Connector	-	-	-	-	GU61740551	1	


35	Rubber protection	-	-	-	-	-	GU35755780	1
36	Cap	-	-	-	-	-	GU25741325	1
37	Rubber spacer	-	-	-	-	-	GU17755300	2
38	Cap	-	-	-	-	-	GU12717600	1
39	Starter relay	-	-	-	-	-	GU19732500	1
40	Front turn signal support	-	-	-	-	-	GU19751300	1
41	Sheath	-	-	-	-	-	GU19750800	1
42	Front turn indicator	-	-	-	-	-	GU14750650	1
43	Front turn indicator	-	-	-	-	-	GU14750650	1
44	Lamp 12V-10W	-	-	-	-	-	GU93450129	4
45	Sheath	-	-	-	-	-	GU93430307	1
46	Nut	-	-	-	-	-	GU92602411	4
47	Front turn indicator	-	-	-	-	-	GU14750650	1
48	Front turn indicator	-	-	-	-	-	GU14750650	1
49	Turn indicator lens	-	-	-	-	-	GU14753750	4
50	Spacer	-	-	-	-	-	GU14753450	2
51	Notched washer	-	-	-	-	-	GU95021110	2
52	Flasher unit	-	-	-	-	-	GU17750520	1
53	Block	-	-	-	-	-	GU17751200	1

Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Transmission box assy., blank	-	-	-	-	GU19350220	1	
2	Hose	-	-	-	-	GU19327701	1	
3	Hose	-	-	-	-	GU19328801	1	
4	Circlip	-	-	-	-	GU90272023	1	
5	Disc	-	-	-	-	GU19327601	1	
6	Spring	-	-	-	-	GU94321099	1	
7	Coupling	-	-	-	-	GU19328001	1	
8	Protection collar	-	-	-	-	GU19548001	1	
9	Spring	-	-	-	-	GU19548101	1	
10	Hose clamp 62/82 mm	-	-	-	-	GU12548201	1	
11	Swing arm	-	-	-	-	GU19540200	1	
12	Pin	-	-	-	-	GU19547000	2	
13	Spacer	-	-	-	-	GU35214300	1	
14	Nut	-	-	-	-	GU14547800	2	
15	Pin	-	-	-	-	GU19555200	1	
16	Screw	-	-	-	-	GU98052550	1	
17	Washer 10,2x18x2	-	-	-	-	GU95004210	1	
18	Nut	-	-	-	-	GU92602210	1	
19	Nut	-	-	-	-	GU92781081	4	
20	Washer	-	-	-	-	GU95004208	4	





Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Battery 12V-24Ah	-	-	-	-	GU28704552	1	
2	Float chamber	-	-	-	-	GU14707000	1	
3	Accumulator fixing wedge	-	-	-	-	GU14705350	1	
4	Clamp	-	-	-	-	GU19704800	1	
5	Cap	-	-	-	-	GU14717600	2	
6	Sheath	-	-	-	-	GU19718600	2	
7	HT coil	-	-	-	-	GU31716560	2	
8	Screw	-	-	-	-	GU98052220	4	
9	Spring washer 5,3X10X0,5	-	-	-	-	GU95129100	4	
10	Nut	-	-	-	-	GU92602205	4	
11	ECU	-	-	-	-	GU19721400	2	
12	Starter relay	-	-	-	-	GU19732500	1	
13	Screw	-	-	-	-	GU98054212	2	
14	Washer 5,25x14x1,5	-	-	-	-	GU95100059	4	
15	Nut	-	-	-	-	GU92602205	2	
16	Bosch rectifier	-	-	-	-	GU17704300	1	
17	Cover	-	-	-	-	GU14704205	2	
18	Screw	-	-	-	-	GU98052245	4	
19	Washer 6,4x12x1,2	-	-	-	-	GU95100141	4	
20	Spacer	-	-	-	-	GU91180627	4	
21	Spring washer 5,3X10X0,5	-	-	-	-	GU95129100	4	
22	Nut	-	-	-	-	GU92602205	8	
23	Voltage regulator BOSCH	-	-	-	-	GU29703800	1	
24	Spacer	-	-	-	-	GU91180605	2	
25	Spring washer 5,3X10X0,5	-	-	-	-	GU95129100	2	
26	Screw	-	-	-	-	GU98054214	2	
27	Block	-	-	-	-	GU19105150	1	
28	Wiring	-	-	-	-	GU19722100	1	
29	Connector 6 vie	-	-	-	-	GU19721700	2	
30	Rubber spacer	-	-	-	-	GU19721500	2	
31	Connector 4 vie	-	-	-	-	GU17756200	1	
32	Pick-up	-	-	-	-	GU63721600	2	
33	Electrical system	-	-	-	-	GU19722200	1	



34	Connector 4 vie	-	-	-	-	-	GU17736300	1
35	Stud bolt	-	-	-	-	-	GU19722600	2
36	Screw	-	-	-	-	-	GU98202510	2
37	Notched washer	-	-	-	-	-	GU95021105	4
38	Wiring	-	-	-	-	-	GU19747400	1
39	Connector 3 vie	-	-	-	-	-	GU61712500	2
40	Connector	-	-	-	-	-	GU61712600	1
41	Rubber spacer	-	-	-	-	-	GU19007700	1
42	Wire	-	-	-	-	-	GU19748200	1
43	Wire	-	-	-	-	-	GU19748000	1
44	Wire	-	-	-	-	-	GU19748300	1
45	Cap	-	-	-	-	-	GU19707100	2
46	Hose clamp 3,6x20,6	-	-	-	-	-	GU14609650	10
47	Protection	-	-	-	-	-	GU19733350	1
48	Screw	-	-	-	-	-	GU98052440	1
49	Hex screw M8X35	-	-	-	-	-	GU98052435	1
50	Sparkplug cap	-	-	-	-	-	GU14717400	2
51	Spark plug NGK B8ES	-	-	-	-	-	GU31717060	2
52	Bosch alternator	-	-	-	-	-	GU17712400	1
53	Hex socket screw M5X45	-	-	-	-	-	GU98620245	3
54	Notched washer	-	-	-	-	-	GU95021105	3
55	Repairing kit	-	-	-	-	-	GU17719900	1
56	Pick-up protection	-	-	-	-	-	GU19722500	1
57	Screw	-	-	-	-	-	GU98280412	2
58	Starter motor Valeo	-	-	-	-	-	GU30730711	1
59	Starter motor revision kit	-	-	-	-	-	GU14730570	1
60	Washer	-	-	-	-	-	GU95004208	2
61	Nut M8X1,25	-	-	-	-	-	GU92602208	1
62	Washer	-	-	-	-	-	GU95004205	2
63	Washer 5,25x14x1,5	-	-	-	-	-	GU95100059	6
64	Screw	-	-	-	-	-	GU98054216	4
65	Ground-battery lead	-	-	-	-	-	GU19748400	1




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Rear master cylinder	-	-	-	-	GU31666990	1	
2	Pump revision kit	-	-	-	-	GU17659350	1	
3	Lever overhaul kit	-	-	-	-	GU19659600	2	
4	Pump connection overhaul unit	-	-	-	-	GU19659500	2	
5	Rear brake lever	-	-	-	-	GU19667500	1	
6	Rear brake lever spring	-	-	-	-	GU19667600	1	
7	Washer 6,15x11x0,8	-	-	-	-	GU95004206	4	
8	Screw	-	-	-	-	GU98052326	2	
9	Special washer	-	-	-	-	GU61013800	2	
10	Notched washer	-	-	-	-	GU95021106	4	
11	Nut	-	-	-	-	GU92602206	4	
12	Connection	-	-	-	-	GU19668000	1	
13	Oil pipe screw *	-	-	-	-	GU95990028	4	
14	Gasket	-	-	-	-	GU25656100	12	
15	Brake line	-	-	-	-	GU17657101	1	
16	Brake light switch	-	-	-	-	GU14657050	2	
17	Rear brake caliper	-	-	-	-	GU23653011	1	
18	Brake caliper rev. kit GRIMECA	-	-	-	29895C	GU66659031	2	
	Brake caliper rev. kit BREMBO	-	-	-	-	GU39659000	3	
19	Pins+spring GRIMECA	-	-	-	29895C	GU31659165	2	
	Pins+spring BREMBO	-	-	-	-	GU39659100	3	
20	Bleeder+cap GRIMECA	-	-	-	29895C	GU31659265	1	
	Bleeder revision kit	-	-	-	-	GU14659200	3	
21	Pads pair GRIMECA	-	-	-	29895C	GU31654665	2	
	Pads pair BREMBO	-	-	-	-	GU27654610	4	
22	Brake caliper cover BREMBO	-	-	-	-	GU39654700	3	
	Brake caliper cover GRIMECA	-	-	-	29895C	GU31654765	1	
23	Screw	-	-	-	-	GU98622422	6	
24	Spring washer 8x15x0,3	-	-	-	-	GU61270300	6	
25	Washer 8,5X18X0,5	-	-	-	-	GU95100250	4	
	Washer 8,5X18X0,8	-	-	-	-	GU95100251	4	
26	Pipe	-	-	-	-	GU19658700	1	
27	Piston ring	-	-	-	-	GU17659650	2	
28	Hose clamp	-	-	-	-	GU62436500	1	

29	Snap ring	-	-	-	-	-	GU90716142	1
30	Hose clamp 3,6x20,6	-	-	-	-	-	GU14609650	2
31	Flexible brake line	-	-	-	-	-	GU14658850	1
32	RH front brake caliper Grimeca	-	-	-	29895C	-	GU31652365	1
33	Rear brake lever	-	-	-	-	-	GU19677000	1
34	Rubber spacer	-	-	-	-	-	GU14251001	1
35	Spring washer	-	-	-	-	-	GU95129260	1
36	Flat washer	-	-	-	-	-	GU95004215	1
37	Split pin	-	-	-	-	-	GU95500227	1
38	Change gear tie rod compl.	-	-	-	-	-	GU19675000	1
40	Nut	-	-	-	-	-	GU92700073	1
41	Block	-	-	-	-	-	GU18257551	1
42	Circlip	-	-	-	-	-	GU90271008	1
43	Pin	-	-	-	-	-	GU95770265	1
44	Washer	-	-	-	-	-	GU95129110	1
45	Split pin	-	-	-	-	-	GU95500222	1
46	Rear master cylinder	-	-	-	-	-	GU31666990	1
47	Rear pump rev. kit	-	-	-	-	-	GU17659352	1
48	Lever	-	-	-	-	-	GU19663300	1
49	Front brake m.cyl.spring	-	-	-	-	-	GU19662600	1
50	Screw	-	-	-	-	-	GU98052325	2
51	Flexible brake line	-	-	-	-	-	GU19657100	1
52	LH front brake caliper Grimeca	-	-	-	29895C	-	GU31652265	1
53	Brake oil tank	-	-	-	-	-	GU19665000	1
54	Cover	-	-	-	-	-	GU14661100	1
55	Diaphragm	-	-	-	-	-	GU14661300	1
56	Rear brake hose	-	-	-	-	-	GU00823950050	1
57	Hose clamp D9	-	-	-	-	-	GU61108500	4
58	Pipe	-	-	-	-	-	GU00823947120	1
59	Cap	-	-	-	-	-	GU12735100	2

		V 35 - V 50 ACC. ELETTRONICA 350-500 1977-1980			GU074	00	TAB N.	07
HANDLEBAR - CONTROLS								
								
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Front brake lever	-	-	-	-	GU19605400	1	
3	Front brake cable	-	-	-	-	GU19625451	1	
4	Clutch lever control	-	-	-	-	GU19605501	1	
6	Cap	-	-	-	-	GU17755800	1	
7	Connector	-	-	-	-	GU61740550	1	
8	Cap	-	-	-	-	GU17755800	1	
9	RH hand grip	-	-	-	-	GU65603500	1	
10	LH hand grip	-	-	-	-	GU65603000	1	
11	Handlebar	-	-	-	-	GU30600310	1	
12	Instrument support	-	-	-	-	GU19501500	1	
13	Silent-block	-	-	-	-	GU14502250	4	
14	Flat washer	-	-	-	-	GU95004215	2	
15	Washer	-	-	-	-	GU95090142	2	
16	Washer	-	-	-	-	GU18577850	2	
17	Screw	-	-	-	-	GU98270627	2	
18	Speedometer	-	-	-	-	GU19761500	1	
19	Speedometer transmission	-	-	-	-	GU19760400	1	
20	Odometer gear	-	-	-	-	GU39762501	1	
21	Tachometer	-	-	-	V50	GU17767260	1	
	Tachometer	-	-	-	V35	GU19767200	1	
	Tachometer	-	-	D	V35	GU17767250	1	
22	Gear Z=14	-	-	-	-	GU14769200	1	
23	Rev counter transmission	-	-	-	-	GU19768100	1	
24	Sheath	-	-	-	-	GU17762200	2	
25	Support	-	-	-	-	GU19766900	1	
26	Lampholder	-	-	-	-	GU14768651	5	
27	Lamp 12V-1,2W	-	-	-	-	GU93450140	5	
28	Screw	-	-	-	-	GU98830225	2	
29	Notched washer	-	-	-	-	GU95021105	2	
30	Lampholder	-	-	-	-	GU14768650	2	
31	Lamp 12v-3w	-	-	-	-	GU93450120	2	
32	LH lights selector	-	-	-	-	GU65738020	1	
33	Connector	-	-	-	-	GU61740551	1	
34	Rubber protection	-	-	-	-	GU35755780	1	
35	Gas lever transmission	-	-	-	-	GU19117550	2	
36	Operator's handbook	-	-	F	-	GU19900002	1	
	Operator's handbook	-	-	D	-	GU19900003	1	
37	Toolkit	-	-	-	-	GU28929940	1	


		V 35 - V 50 ACC. ELETTRONICA 350-500 1977-1980	GU074	00	TAB N.	08		
WHEELS								
								
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.

2	Front wheel	-	-	-	-	GU19610300	1	
3	Bearing	-	-	-	-	GU92204217	3	
4	Internal spacer	-	-	-	-	GU39615201	1	
5	Front brake disc	-	-	-	-	GU63635720	2	
6	Screw	-	-	-	-	GU98052460	6	
7	Nut	-	-	-	-	GU92630508	6	
8	Spacer	-	-	-	-	GU91181803	1	
9	Front wheel spindle	-	-	-	-	GU19614100	1	
10	Washer 17X27X2	-	-	-	-	GU95004217	1	
11	Nut M16X1,5	-	-	-	-	GU92602516	1	
12	Spacer	-	-	-	-	GU39616301	1	
13	Counterweight	-	-	-	-	GU14616150	2	
15	Rear wheel	-	-	-	-	GU19630600	1	
16	LH rubber coupling	-	-	-	-	GU19632502	6	
17	Bearing	-	-	-	-	GU92204218	1	
18	Protection	-	-	-	-	GU19636400	1	
19	Bearing internal spacer	-	-	-	-	GU19634000	1	
20	Spacer	-	-	-	-	GU19634100	1	
21	Rear wheel spindle	-	-	-	-	GU19633300	1	
22	Washer	-	-	-	-	GU14634400	1	
23	Nut M6X1,5	-	-	-	-	GU92602316	1	





Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Front fork	-	-	-	-	GU19490305	1	
2	Lower fork plate	-	-	-	-	GU39494002	1	
3	Screw	-	-	-	-	GU98620555	2	
4	Spacer	-	-	-	-	GU91181110	2	
5	Washer 10,2x18x2	-	-	-	-	GU95004210	2	
6	Washer	-	-	-	-	GU62493200	1	
7	Upper plate	-	-	-	-	GU39493101	1	
8	Screw M8X35	-	-	-	-	GU98620435	1	
9	Screw M10X40	-	-	-	-	GU98620540	4	
10	Bush	-	-	-	-	GU14516600	1	
11	Plug	-	-	-	-	GU17517700	1	
12	RH sleeve	-	-	-	-	GU195225001	1	
13	LH sleeve	-	-	-	-	GU195226001	1	
14	Stud bolt	-	-	-	-	GU96508021	4	
15	Oil unload plug	-	-	-	-	GU98620312	2	
16	Washer 6,25x10x1,5	-	-	-	-	GU95100116	2	
17	Oil seal	-	-	-	-	GU90403144	4	
18	Dust cover	-	-	-	-	GU53524540	2	
19	Sleeve	-	-	-	-	GU39525401	2	
20	Fork shock absorber	-	-	-	-	GU14526407	2	
21	Plunger	-	-	-	-	GU53527840	2	
22	Spring seat	-	-	-	-	GU53527940	2	
23	Fork spring	-	-	-	-	GU19526600	2	
24	Circlip	-	-	-	-	GU90271012	2	
25	Plug	-	-	-	-	GU39504501	2	
26	O-ring	-	-	-	-	GU90706202	2	
27	Stud bolt	-	-	-	-	GU19504800	2	
28	Cup	-	-	-	-	GU53527640	2	
29	Screw	-	-	-	-	GU98623430	2	
30	Gasket 8,25x15x1	-	-	-	-	GU12154200	2	
31	Washer	-	-	-	-	GU95004208	2	
32	Nut	-	-	-	-	GU92602210	2	
33	RH headlight supp.	-	-	-	-	GU194961001	1	


34	LH headlight supp.	-	-	-	-	-	GU194962001	1
35	O-ring	-	-	-	-	-	GU39492701	4
36	Handlebar U-bolt	-	-	-	-	-	GU19500200	1
37	Screw	-	-	-	-	-	GU98830430	4
38	Plug	-	-	-	-	-	GU61514940	1
39	Steering race	-	-	-	00201N	-	GU61515240	1
40	Ball	-	-	-	-	-	GU92295704	44
41	Shock absorber	-	-	-	-	-	GU23999290	2
42	Spring	-	-	-	-	-	GU19552300	2
43	Flat washer	-	-	-	-	-	GU95004215	4
44	Washer	-	-	-	-	-	GU95100255	2
45	Washer	-	-	-	-	-	GU95000208	2
46	Screw	-	-	-	-	-	GU98822416	4
47	Bush	-	-	-	-	-	GU10551600	8



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Frame	-	-	-	-	GU19400100	1	
2	Washer 10,2x18x2	-	-	-	-	GU95004210	4	
3	Nut	-	-	-	-	GU92602210	4	
4	Lock	-	-	-	-	GU19782520	1	
5	RH cradle arm	-	-	-	-	GU19420300	1	
6	LH cradle arm	-	-	-	-	GU19422100	1	
7	Screw	-	-	-	-	GU98622522	4	
8	Washer	-	-	-	-	GU95120105	4	
9	Central stand	-	-	-	-	GU19430305	1	
10	Rubber pedal	-	-	-	-	GU13432640	1	
11	Lateral stand spring	-	-	-	-	GU12434001	2	
12	Screw	-	-	-	-	GU98054530	2	
13	Spacer	-	-	-	-	GU91181114	2	
14	Spring	-	-	-	-	GU94322215	1	
15	Washer	-	-	-	-	GU95000210	2	
16	Nut M10x1,5	-	-	-	-	GU92630510	2	
17	Lateral stand	-	-	-	-	GU19432000	1	
18	Lockup rubber	-	-	-	-	GU19433000	1	
19	Pin	-	-	-	-	GU99105129	1	
20	Spring	-	-	-	-	GU19434000	2	
21	Plate	-	-	-	-	GU19418200	1	
22	Screw	-	-	-	-	GU98054418	4	
23	Washer	-	-	-	-	GU95004208	4	
24	RH pipe	-	-	-	-	GU39440700	1	
25	LH pipe	-	-	-	-	GU39441800	1	
26	Screw	-	-	-	-	GU98820430	2	
27	Nut M8X1,25	-	-	-	-	GU92602208	2	
28	Front footrest	-	-	-	-	GU39443200	2	
29	Rear footrest	-	-	-	-	GU61442300	2	
30	Drift	-	-	-	-	GU19705900	4	
31	Rear mudguard supp.	-	-	-	-	GU19439100	2	
32	Screw	-	-	-	V35	GU98822418	4	
	Screw	-	-	-	V50	GU98822420	2	

33	Nut	-	-	-	-	-	GU92630508	4
34	Seat clip	-	-	-	-	-	GU19462050	1
35	Rubber spacer	-	-	-	-	-	GU61462800	1
36	Screw	-	-	-	-	-	GU98054312	2
37	Notched washer	-	-	-	-	-	GU95021106	2
38	Nut	-	-	-	-	-	GU92602206	2
39	Pin M10x250	-	-	-	-	-	GU53429500	1
40	Pin M10x205	-	-	-	-	-	GU98110199	1
41	Washer 10,2x18x2	-	-	-	-	-	GU95004210	3
42	Nut	-	-	-	-	-	GU92602210	2
43	Bush	-	-	-	-	-	GU19017000	2
44	Hex screw M6X22	-	-	-	-	-	GU98054322	1
45	Nut	-	-	-	-	-	GU92602206	1
46	Plug	-	-	-	-	-	GU39515000	2
47	Rubber spacer	-	-	-	-	-	GU91551085	2
48	Screw	-	-	-	-	-	GU98052350	2
49	Washer 6,5X17X1.5	-	-	-	-	-	GU95100139	8
50	Spacer	-	-	-	-	-	GU91180725	2
51	Nut M6x1	-	-	-	-	-	GU92630106	2
52	Clamp	-	-	-	-	-	GU19716801	2
53	Rubber spacer	-	-	-	-	-	GU91551085	2
54	Screw	-	-	-	-	-	GU98052220	2
55	Washer 5,25x14x1,5	-	-	-	-	-	GU95100059	2
56	Nut	-	-	-	-	-	GU92630105	2
57	Drift	-	-	-	-	-	GU39103400	2
58	Drift	-	-	-	-	-	GU14107100	1
59	Hose clamp 3,6x20,6	-	-	-	-	-	GU14609650	1
60	Eyelet	-	-	-	-	-	GU19436500	2
61	Screw	-	-	-	-	-	GU98822420	1
62	Washer	-	-	-	-	-	GU95000208	1
63	Spring washer	-	-	-	-	-	GU95021108	1
64	Nut M8X1,25	-	-	-	-	-	GU92602208	1
65	Clamp	-	-	-	-	-	GU19704100	1
66	Screw	-	-	-	-	-	GU98052220	2
67	Rubber spacer	-	-	-	-	-	GU91551085	2
68	Washer 5,25x14x1,5	-	-	-	-	-	GU95100059	2
69	Nut	-	-	-	-	-	GU92630105	2
70	Bush 19 mm	-	-	-	-	-	GU18252050	4
71	Screw	-	-	-	-	-	GU98052565	2
72	Screw	-	-	-	-	-	GU98052555	2


 V 35 - V 50 ACC. ELETTRONICA 350-500 1977-1980		GU074		00		TAB N.		11	
DRIVE SHAFT									
									
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.	
1	Drive shaft	-	-	-	V50	-	GU19064150	1	
	Drive shaft	-	-	-	V35	-	GU19064100	1	
2	Plug	-	-	-	-	-	GU19065400	1	
3	Connecting rod	-	-	-	-	-	GU19061500	2	
4	Connecting rod screw	-	-	-	-	-	GU61062201	4	
5	Nut	-	-	-	-	-	GU61062401	4	
6	Big end bushing	-	-	-	-	-	GU61062012	4	
	Big end bushing	-	-	-	00597N-std	-	GU61062010001	4	
7	Crankshaft bearing	-	-	-	std	-	GU61065600	2	
	C-case bushing insert drift	-	-	-	-	-	GU61065602	2	
8	C-case bushing insert drift	-	-	-	std	-	GU19066500	2	
9	Half ring	-	-	-	std	-	GU19066400	2	
10	Piston	-	-	-	V35	-	GU19060400	2	
	Piston	-	-	-	V50	-	GU19060450	2	
11	Piston ring	-	-	-	V35	-	GU19060700	4	
	Ring	-	-	-	V50	-	GU19060750	4	
12	Oil scraper ring	-	-	-	V50	-	GU19061050	2	
	Piston ring	-	-	-	V35	-	GU19061000	2	
13	Piston pin	-	-	-	V35	-	GU19061235	2	
	Piston pin	-	-	-	V50	-	GU19061250	2	
14	Ring	-	-	-	-	-	GU61061300	4	
15	Piston	-	-	-	V35	-	GU19060400	2	
	Piston	-	-	-	V50	-	GU19060450	2	
16	Pistonring set	-	-	-	V35	-	GU19060600	1	
	Piston rings set	-	-	-	V50	-	GU19060650	1	
17	Clutch drum	-	-	-	-	-	GU19080300	1	
18	Screw	-	-	-	-	-	GU19067700	6	
19	Washer 8,4X13X0,8	-	-	-	-	-	GU14615901	6	
20	Chain ring MOTOPLAT	-	-	-	-	-	GU19067900	1	
21	Screw	-	-	-	-	-	GU98054318	6	
22	Nut M6x1	-	-	-	-	-	GU92630106	6	
23	Transmission key	-	-	-	-	-	GU91701350	1	
24	Cam	-	-	-	-	-	GU19721000	1	
25	Rubber spacer	-	-	-	-	-	GU61066800	1	
26	Bushing	-	-	-	-	-	GU19061810	2	



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Carburettor RH	-	-	-	V35	GU19112610	1	
	Carburettor RH	-	-	-	V50	GU19112650	1	
	Carburettor RH	-	-	D	V35	GU19112600	1	
2	Carburettor LH	-	-	D	V35	GU19112601	1	
	Carburettor LH	-	-	-	V35	GU19112611	1	
	Carburettor LH	-	-	-	V50	GU19112651	1	
3	Carburettor flange	-	-	-	-	GU61114300	2	
4	Hose clamp	-	-	-	-	GU93305025	4	
5	Manifold	-	-	-	-	GU19114400	2	
6	Gasket ring	-	-	-	-	GU90706315	2	
7	Screw	-	-	-	-	GU98054214	4	
8	Washer	-	-	-	-	GU95004205	4	
9	Intake manifold	-	-	-	-	GU19114300	1	
10	Hose clamp	-	-	-	-	GU93305092	1	
11	Pipe	-	-	-	-	GU17114650	1	
12	Breather pipe	-	-	-	-	GU95985532	1	
13	Hose clamp 3,6x20,6	-	-	-	-	GU14609650	1	
14	Air filter support	-	-	-	-	GU19155775	1	
15	Cover	-	-	-	-	GU19156700	1	
16	Rear hose	-	-	-	-	GU19156900	1	
17	Breather pipe	-	-	-	-	GU19156000	1	
18	Ring	-	-	-	-	GU17113450	1	
19	Air filter	-	-	-	-	GU17113651	1	
20	Filter cover	-	-	-	-	GU17114050	1	
21	Plate	-	-	-	-	GU19114100	1	
22	Washer 5,25x14x1,5	-	-	-	-	GU95100059	1	
23	Nut	-	-	-	-	GU92670305	1	
24	Screw	-	-	-	-	GU98052222	1	
25	Washer 5,25x14x1,5	-	-	-	-	GU95100059	1	
26	Rubber spacer	-	-	-	-	GU91551085	1	
27	Nut	-	-	-	-	GU92630105	1	
28	Fuel pipe union cap	-	-	-	-	GU13934600	1	
29	Hose clamp	-	-	-	-	GU61108400	2	



30	Hose clamp D9	-	-	-	-	-	GU61108500	2
31	Starter	-	-	-	-	-	GU23133100	1
32	Choke cable	-	-	-	-	-	GU19133500	1
33	LH choke cable	-	-	-	-	-	GU19134000	1
34	RH exhaust manifold	-	-	-	-	-	GU19120700	1
35	LH exhaust manifold	-	-	-	-	-	GU19120705	1
36	Exhaust pipe gasket	-	-	-	-	-	GU61025200	2
37	Spacer	-	-	-	-	-	GU61025400	4
38	Ring nut	-	-	-	-	-	GU61025100	2
39	Special washer	-	-	-	-	-	GU61013800	4
40	Nut	-	-	-	-	-	GU92701062	4
41	LH silencer	-	-	-	-	-	GU19122900	1
42	RH silencer	-	-	-	-	-	GU19123000	1
43	Hose clamp	-	-	-	-	-	GU61126920	2
44	Pipe	-	-	-	-	-	GU19121100	1
45	Screw	-	-	-	-	-	GU98052330	2
46	Washer	-	-	-	-	-	GU95000206	2
47	Nut	-	-	-	-	-	GU92602206	2
48	Hex screw M10X22	-	-	-	-	-	GU98054522	2
49	Notched washer	-	-	-	-	-	GU95021110	2
50	Nut	-	-	-	-	-	GU92602410	2
51	Gasket envelope	-	-	-	-	-	GU39939900	2
52	Cap	-	-	-	-	-	GU13937000	4
53	Wire tensioner screw	-	-	-	-	-	GU53937200	2
54	Nut	-	-	-	-	-	GU19938880	2
55	Pipe	-	-	-	-	-	GU49938900	2
56	Nut	-	-	-	-	-	GU12937300	4
57	Screw	-	-	-	-	-	GU13937900	2
58	Starter device cover	-	-	-	-	-	GU17937450	2
60	Spring	-	-	-	-	-	GU25937600	2
61	Starter valve	-	-	-	-	-	GU13937800	2
62	Adj.min.eng.speed screw	-	-	-	-	-	GU13936200	2
63	Spring	-	-	-	-	-	GU13936300	2
64	Gas valve adjuster screw	-	-	-	-	-	GU13936600	2
65	Spring	-	-	-	-	-	GU13936700	2
66	Screw	-	-	-	-	-	GU13932800	4
67	Washer	-	-	-	-	-	GU13932900	4
68	Valve cover	-	-	-	-	-	GU53935000	2
70	Wire tensioner screw	-	-	-	-	-	GU12937200	2
71	Gas valve return spring	-	-	-	-	-	GU53937100	2
72	Conical pin	-	-	-	-	-	GU19934900	2
	Conical pin	-	-	D	V35	-	GU61934940	2
73	Conical pin clip	-	-	-	-	-	GU55938585	2
74	Gas valve 40	-	-	-	-	-	GU61934800	2
75	Starter jet 60	-	-	-	-	-	GU19936000	2
77	Needle valve 260AH	-	-	-	-	-	GU19935500	2
78	Idle jet 40	-	-	-	-	-	GU19935900	2
79	Gasket	-	-	-	-	-	GU14931750	2
80	Needle valve	-	-	-	-	-	GU19934600	2
82	Fuel pipe union cap	-	-	-	-	-	GU13934600	2
84	Cap fixing screw	-	-	-	-	-	GU10934900	2
85	Float	-	-	-	-	-	GU61934300	2
86	Float pin	-	-	-	-	-	GU13933100	2
88	Float chamber	-	-	-	-	-	GU10934400	2
90	Main jet 102	-	-	-	V35	-	GU19935700	2
	Main jet 105	-	-	-	V50	-	GU19935750	1
	Main jet 98	-	-	D	V35	-	GU39935701	1


91	Plug with OR	-	-	-	-	-	GU10933700	2
92	Gasket	-	-	-	-	-	GU19113900	1
93	Gasket ring	-	-	-	-	-	GU90706572	1
94	Gasket ring	-	-	-	-	-	GU90706552	1



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Primary gear shaft Z=11	-	-	-	-	GU19210501	1	
2	Gear conduttore 5a Z=22	-	-	-	-	GU19212000	1	
3	Washer	-	-	-	-	GU39215400	5	
4	Circlip	-	-	-	-	GU90271122	5	
5	Gear conduttore 5a Z=22	-	-	-	-	GU19211800	1	
6	Gear conduttore 3a Z=18	-	-	-	-	GU19211400	1	
7	Thrust washer	-	-	-	-	GU19214600	1	
8	Gear conduttore 2a Z=15	-	-	-	-	GU19211300	1	
9	Washer	-	-	-	-	GU43070940	1	
10	Ball bearing	-	-	-	-	GU92201415	1	
11	Clearance washer	-	-	-	-	GU39238100	1	
12	Nut	-	-	-	-	GU10054100	1	
13	Bearing 20X47X14	-	-	-	-	GU92201220	1	
14	Driven shaft	-	-	-	-	GU19213600	1	
15	Spacer	-	-	-	-	GU19212900	1	
16	Bearing 20X47X14	-	-	-	-	GU92201220	1	
17	Spacer	-	-	-	-	GU19213700	1	
18	Gasket ring 18,77X1,78	-	-	-	-	GU90706188	1	
19	Circlip	-	-	-	-	GU90271121	1	
20	Gear	-	-	-	-	GU19214501	1	
21	Gear condotto 3a Z=23	-	-	-	-	GU19214800	1	
22	Gear condotto 4a Z=23	-	-	-	-	GU19215100	1	
23	Gear condotto 5a Z=20	-	-	-	-	GU19215200	1	
24	Gear	-	-	-	-	GU19214001	1	
26	Washer	-	-	-	-	GU43070940	1	
27	Ball bearing	-	-	-	-	GU92201415	1	
28	Thrust washer	-	-	-	-	GU39239300	1	
29	Circlip	-	-	-	-	GU90271115	1	
30	Shift cam	-	-	-	-	GU19234400	1	
31	Pin	-	-	-	-	GU19234600	4	
32	Spacer 1 mm	-	-	-	-	GU19355300	1	
33	Snap ring	-	-	-	-	GU90271020	1	
34	Fork AP	-	-	-	-	GU39231270	1	


35	Fork AS	-	-	-	-	-	GU39231070	2
36	Roller	-	-	-	-	-	GU19235220	3
37	Split pin	-	-	-	-	-	GU95401320	3
38	Pre-selector kit	-	-	-	01397N	-	GU20999520	1
39	Spring	-	-	-	-	-	GU61238200	1
	Spring	-	-	-	01397N	-	GU28238261	1
40	Spacer	-	-	-	01397N	-	GU20208520	1
	Bush	-	-	-	-	-	GU91182010	1
41	Shift lever	-	-	-	-	-	GU19258220	1
42	Screw	-	-	-	-	-	GU98052325	1
43	Notched washer	-	-	-	-	-	GU95021106	1
44	Gearbox pedal linkage rod	-	-	-	-	-	GU19257800	1
45	Fork	-	-	-	-	-	GU12626800	1
46	Nut	-	-	-	-	-	GU92602206	1
47	Washer	-	-	-	-	-	GU95129110	2
48	Washer 6,15x11x0,8	-	-	-	-	-	GU95004206	1
49	Split pin	-	-	-	-	-	GU95500222	2
50	Pin	-	-	-	-	-	GU95770265	1
51	Lever	-	-	-	-	-	GU19256900	1
52	Screw	-	-	-	-	-	GU98052325	1
53	Notched washer	-	-	-	-	-	GU95021106	1
54	Complete gearchange lever	-	-	-	-	-	GU19250900	1
55	Rubber spacer	-	-	-	-	-	GU14251001	1
56	Spring washer	-	-	-	-	-	GU95129260	1
57	Gear rinvio AP Z=24	-	-	-	V35	-	GU19211101	1
	Gear rinvio AP Z=25	-	-	D	V35	-	GU19211106	1
	Gear rinvio AP Z=23	-	-	-	V50	-	GU19211151	1
58	Bush	-	-	-	-	-	GU19266700	1
59	Clearance washer	-	-	-	-	-	GU39238100	1
60	Nut	-	-	-	-	-	GU10054100	1

		V 35 - V 50 ACC. ELETTRONICA 350-500 1977-1980		GU074	00	TAB N.	14	
CRANKCASE								
								
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Crankcase	-	-	-	-	GU19000100	1	
2	Stud bolt	-	-	-	-	GU96451455	4	
3	Stud bolt	-	-	-	-	GU96451430	4	
4	Stud bolt	-	-	-	-	GU96451435	2	
5	Locating dowel	-	-	-	-	GU61002000	4	
6	Spring washer 8x15x0,3	-	-	-	-	GU61270300	10	
7	Nut M8X1,25	-	-	-	-	GU92602208	10	
8	Union	-	-	-	-	GU19003800	1	
9	Locating dowel	-	-	-	-	GU61002100	2	
10	Plug	-	-	-	-	GU19016301	1	
11	Gasket	-	-	-	-	GU90706252	1	
13	Gasket ring	-	-	-	-	GU90405367	1	
14	Timing system cover	-	-	-	-	GU19001400	1	
15	Gasket	-	-	-	-	GU19001200	1	
16	Hex socket screw M6X25	-	-	-	-	GU98622325	26	
17	Screw M6X30	-	-	-	-	GU98620330	2	
18	Gasket ring 28x38x7	-	-	-	-	GU90402840	1	
19	Motor oil cup	-	-	-	-	GU19003502	1	
20	Sump gasket	-	-	-	-	GU19003600	1	
21	Oil level plug	-	-	-	-	GU95980214	1	
22	Gasket	-	-	-	-	GU10528900	1	
23	Gasket	-	-	-	-	GU90706523	1	
24	Cover	-	-	-	-	GU18001650	1	
25	O-ring 17,13x2,62	-	-	-	-	GU90706170	1	
26	Cover, blank	-	-	-	-	GU19003400	1	
27	O-ring	-	-	-	-	GU90706444	1	
28	Oil filler plug	-	-	-	-	GU19004900	1	
29	Gasket ring	-	-	-	-	GU90706282	1	
30	Oil unload plug	-	-	-	-	GU12003702	1	
31	Gasket 20,1x28x2	-	-	-	-	GU95100709	1	
32	Screw m8x90	-	-	-	-	GU98052490	1	
33	Gasket 8,25x15x1	-	-	-	-	GU12154200	1	
34	Engine oil seal kit	-	-	-	-	GU19999501	1	
35	Engine set gasket	-	-	-	V50	GU19999051	1	
	Engine set gasket	-	-	-	V35	GU19999001	1	


Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.	
									

Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	RH cylinder head	-	-	-	V50	-	GU19022150	1
	LH cylinder head	-	-	-	V35	-	GU19022110	1
	RH cylinder head	-	-	D	V35	-	GU19022100	1
2	LH cylinder head	-	-	-	V50	-	GU19022250	1
	LH cylinder head	-	-	-	V50	-	GU19022210	1
	LH cylinder head	-	-	D	V35	-	GU19022200	1
3	Valve guide	-	-	-	-	-	GU61036801	4
4	Snap ring	-	-	-	-	-	GU90353009	4
5	Stud bolt	-	-	-	-	-	GU96506042	4
6	Anti-vibration plate	-	-	-	-	-	GU19025300	4
7	Screw	-	-	-	-	-	GU98822325	4
8	Oil seal	-	-	-	-	-	GU19037820	4
9	Valves cover	-	-	-	-	-	GU19023501	2
10	Gasket	-	-	-	-	-	GU19023700	2
11	Nut M10X1,5	-	-	-	-	-	GU92603010	4
12	Column nut	-	-	-	-	-	GU13021900	4
13	Washer 10,5X18X0,8	-	-	-	-	-	GU95129180	4
14	Stud bolt	-	-	-	-	-	GU96510182	4
15	Stud bolt 125 mm	-	-	-	-	-	GU96510125	4
16	Hex socket screw M6X25	-	-	-	-	-	GU98622325	12
17	Cylinder, complete	-	-	-	V35	-	GU19060101	2
	Cylinder, complete	-	-	-	V50	-	GU19060151	2
18	Locating dowel	-	-	-	-	-	GU61002100	2
19	Cylinder head gasket	-	-	-	V50	-	GU19022050	2
	Cylinder head gasket	-	-	-	V35	-	GU19022000	2
20	Hex socket screw M8X45	-	-	-	-	-	GU98620445	2
21	Spring washer 8x15x0,3	-	-	-	-	-	GU61270300	2
22	Gasket	-	-	-	-	-	GU90706252	4
23	O-ring	-	-	-	-	-	GU61027200	2
24	Cylinder base gasket	-	-	-	-	-	GU19020800	2
25	Gasket	-	-	-	-	-	GU19115500	2
26	RH intake manifold	-	-	D	V35	-	GU19115000	1
	RH intake manifold	-	-	-	-	-	GU19115050	1

27	LH intake manifold	-	-	D	V35	-	GU19115001	1
	LH intake manifold	-	-	-	-	-	GU19115051	1
28	Screw	-	-	-	-	-	GU98310610	2
29	Washer 6,25x10x1,5	-	-	-	-	-	GU95100116	2
30	Special washer	-	-	-	-	-	GU61013800	2
31	Hose clamp	-	-	-	-	-	GU19718000	2




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Intake valve	-	-	-	V35	-	GU19036010	2
	Intake valve	-	-	-	V50	-	GU19036050	2
	Intake valve	-	-	D	V35	-	GU19036000	2
2	Exhaust valve	-	-	D	V35	-	GU19036100	2
	Exhaust valve	-	-	-	-	-	GU23036100	2
3	Spring	-	-	-	-	-	GU61037600	4
4	Spring	-	-	-	-	-	GU61037500	4
5	Upper cup	-	-	-	-	-	GU61038000	4
6	Half-cone	-	-	-	-	-	GU61038100	8
7	Rocker arm assy.	-	-	-	-	-	GU19030500	4
8	Screw	-	-	-	-	-	GU19034000	4
9	Nut M6x1	-	-	-	-	-	GU92602406	4
10	Rocker shaft	-	-	-	-	-	GU19032000	2
11	Clearance washer	-	-	-	-	-	GU19032300	4
12	Circlip	-	-	-	-	-	GU90271018	4
13	Lower cup	-	-	-	-	-	GU61037000	4
14	Spacer	-	-	-	-	-	GU19032900	8
15	Hose	-	-	-	-	-	GU19027500	2
16	Camshaft	-	-	-	-	-	GU19053301	1
17	Gear	-	-	-	-	-	GU19054500	1
18	Bolt	-	-	-	-	-	GU61054900	2
19	Camshaft chain	-	-	-	-	-	GU19058000	1
20	Timing system chain guide	-	-	-	-	-	GU19058400	1
21	Hex socket screw M6X16	-	-	-	-	-	GU98622316	2
22	Washer 6,15x11x0,8	-	-	-	-	-	GU95004206	2
23	Sector	-	-	-	-	-	GU19055700	2
24	Snap ring	-	-	-	-	-	GU90353029	1
25	Tappet	-	-	-	-	-	GU19045861	4
26	Rocker arms axis	-	-	-	-	-	GU19045001	4




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Belleville spring	-	-	-	-	GU19084100	1	
2	Pressure plate	-	-	-	-	GU19082501	1	
3	Screw	-	-	-	-	GU98054214	3	
4	Washer	-	-	-	-	GU95004205	3	
5	Nut	-	-	-	-	GU92630105	3	
6	Cup	-	-	-	-	GU19083401	1	
7	Driven clutch disc	-	-	-	-	GU27084420	1	
8	Rod	-	-	-	-	GU20085720	1	
9	Inner body	-	-	-	-	GU14086000	1	
10	Thrust bearing	-	-	-	-	GU12087001	1	
11	Outer body	-	-	-	-	GU14086100	1	
12	O-ring 17,13x2,62	-	-	-	-	GU90706170	1	
13	Clutch release shaft	-	-	-	-	GU14090201	1	
14	Adjuster screw	-	-	-	-	GU14090400	1	
15	Nut M8X1	-	-	-	-	GU92602508	1	
16	Lever return spring	-	-	-	-	GU94321105	1	
17	Pin 7x39	-	-	-	-	GU95780271	1	
18	Split pin	-	-	-	-	GU95500222	1	
19	Oil seal	-	-	-	-	GU90402736	1	
20	Transmission shaft Z=13	-	-	-	V35	GU19210700	1	
	Transmission shaft Z=14	-	-	-	V50	GU19210750	1	
21	Gasket ring 6x16x7	-	-	-	-	GU90400616	1	
22	Spacer	-	-	-	-	GU19213700	1	
23	Gasket ring 18,77X1,78	-	-	-	-	GU90706188	1	
24	Nut	-	-	-	-	GU19356700	1	
25	Clutch cable	-	-	-	-	GU19093052	1	
26	Clutch drum	-	-	-	-	GU19200401	1	
27	Plug	-	-	-	-	GU93180220	1	
28	Ball bearing 20x42x12	-	-	-	-	GU92201120	1	
29	Bearings support Plate	-	-	-	-	GU19203400	1	
30	Screw	-	-	-	-	GU98054314	3	
31	Washer 6,4x10x0,7	-	-	-	-	GU14217901	3	
32	Screw M6X30	-	-	-	-	GU98620330	11	

33	Screw M8X35	-	-	-	-	-	GU98620435	6
34	Starter lever	-	-	-	-	-	GU19260400	1
35	Hex screw M8x30	-	-	-	-	-	GU98052430	1
36	Washer	-	-	-	-	-	GU95004208	1
37	Starter shaft	-	-	-	-	-	GU19264000	1
38	Gasket ring 18,77X1,78	-	-	-	-	-	GU90706188	1
39	Oil seal	-	-	-	-	-	GU90401832	1
40	Spring cable lever	-	-	-	-	-	GU61265700	1
41	Clearance washer	-	-	-	-	-	GU19032300	2
42	Circlip	-	-	-	-	-	GU90271018	1
43	Gear rinvio Z=23	-	-	-	V35	-	GU19211105	1
	Gear rinvio Z=25	-	-	-	V50	-	GU19211150	1
44	Gear	-	-	-	-	-	GU19266601	1
45	Spring	-	-	-	-	-	GU19266200	1
46	Slide piece	-	-	-	-	-	GU19263300	1
47	Screw	-	-	-	-	-	GU98054314	2
48	Safety plate	-	-	-	-	-	GU19235900	1
49	Special screw	-	-	-	-	-	GU19202600	1


	V 35 - V 50 ACC. ELETTRONICA 350-500 1977-1980	GU074	00	TAB N.	18
	BENDIX STARTER MOTOR				




Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
2	Plate	-	-	-	-	GU14731806	1	
3	Screw	-	-	-	-	GU98820450	1	
4	Screw	-	-	-	-	GU98820435	1	
5	Screw	-	-	-	-	GU98822420	1	
6	Washer	-	-	-	-	GU95004208	2	
7	Nut M8X1,25	-	-	-	-	GU92602208	2	
8	Support	-	-	-	-	GU19733800	1	
9	Nut	-	-	-	-	GU92630105	2	
10	Protection	-	-	-	-	GU19733200	1	
11	Screw	-	-	-	-	GU98310612	2	
12	Washer 6,15x11x0,8	-	-	-	-	GU95004206	2	
13	Starting relay	-	-	-	-	GU14707605	1	
14	Male connector	-	-	-	-	GU93400863	2	
15	Screw	-	-	-	-	GU98052220	2	
16	Starter motor revision kit	-	-	-	-	GU14730571	0	
17	Ground-battery lead	-	-	-	-	GU19748400	3	



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Oil pump assy.	-	-	-	-	GU19146400	1	
3	Roller bearing 10x22x20	-	-	-	-	GU92252210	1	
4	Oil pump shaft assy.	-	-	-	-	GU19147800	1	
5	Inner rotor	-	-	-	-	GU19148400	1	
6	Outer rotor	-	-	-	-	GU19148600	1	
7	Transmission key	-	-	-	-	GU13148300	1	
8	Oil pump gear	-	-	-	-	GU19147700	1	
9	Washer 10,5x16x1	-	-	-	-	GU19149800	1	
10	Nut M10x1,25	-	-	-	-	GU92602510	1	
11	Screw M6X30	-	-	-	-	GU98620330	3	
12	Pin	-	-	-	-	GU95512062	2	
13	Oil filter	-	-	-	-	GU19152200	1	
14	Screw	-	-	-	-	GU98054314	1	
15	Plate	-	-	-	-	GU95187006	1	
16	Oil filter	-	-	-	-	GU19153000	1	
17	Oil valve cpl.	-	-	-	-	GU10158201	1	
18	Valve body	-	-	-	-	GU10158701	1	
19	Piston	-	-	-	-	GU12150900	1	
20	Valve spring	-	-	-	-	GU94321072	1	
21	Bottom	-	-	-	-	GU12150700	1	
22	Washer 14,5X20X1	-	-	-	-	GU95100523	1	
23	Plug	-	-	-	-	GU12159000	1	
24	Pressure sensor	-	-	-	-	GU17768750	1	
25	Gasket 12,25	-	-	-	-	GU12006400	1	
26	Union	-	-	-	-	GU19055800	1	
27	Plate	-	-	-	-	GU19055900	1	
28	Gasket 12,25	-	-	-	-	GU12006400	2	
29	Breather pipe	-	-	-	-	GU19159600	1	
30	Hose clamp	-	-	-	-	GU61108400	3	
31	Hose clamp	-	-	-	-	GU12157800	1	
32	Breather	-	-	-	-	GU19159300	1	
33	Gasket 8,25x15x1	-	-	-	-	GU12154200	1	



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Gearbox cover	-	-	-	-	GU19200800	1	
2	Bearing 15x35x11	-	-	-	-	GU92204215	2	
3	Oil seal	-	-	-	-	GU90402737	1	
4	O-ring 13,95x2,92	-	-	-	-	GU90706140	1	
5	Plate	-	-	-	-	GU19213800	1	
6	Screw	-	-	-	-	GU98054314	3	
7	Washer 6,4x10x0,7	-	-	-	-	GU14217901	5	
8	Plate	-	-	-	-	GU19235800	1	
9	Screw	-	-	-	-	GU98054314	2	
10	Gasket	-	-	-	-	GU19200300	1	
11	Sensor	-	-	-	-	GU19207220	1	
12	Gasket 8,25x15x1	-	-	-	-	GU12154200	1	
13	Screw M12x1,25	-	-	-	-	GU19237800	1	
14	Low nut M12x1,25	-	-	-	-	GU92602512	1	
15	Gasket	-	-	-	-	GU19201120	1	
16	Locating dowel	-	-	-	-	GU61002100	2	
17	Transmission cage	-	-	-	-	GU19200201	1	
18	Screw M6X30	-	-	-	-	GU98620330	7	
19	Screw M8X35	-	-	-	-	GU98620435	4	
20	Pawl	-	-	-	-	GU55234700	1	
21	Lever return spring	-	-	-	-	GU94321067	1	
22	Breather plug	-	-	-	-	GU19206501	1	
23	Gasket	-	-	-	-	GU10528900	2	
24	Oil plug	-	-	-	-	GU12022600	1	
25	O-ring 20,24X2,62	-	-	-	-	GU90706203	1	
26	Oil level plug	-	-	-	-	GU95980214	1	
27	Locating dowel	-	-	-	-	GU61002100	2	
28	Plug	-	-	-	-	GU19204100	1	
29	Oil seal	-	-	-	-	GU90401832	1	
30	Ball bearing 20x42x12	-	-	-	-	GU92201120	1	
31	Gear box assy	-	-	-	V50	GU19991550	1	



Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Gearbox cover	-	-	-	-	GU19200800	1	
2	Bearing 15x35x11	-	-	-	-	GU92204215	2	
3	Oil seal	-	-	-	-	GU90402737	1	
4	O-ring 13,95x2,92	-	-	-	-	GU90706140	1	
5	Plate	-	-	-	-	GU19213800	1	
6	Screw	-	-	-	-	GU98054314	3	
7	Washer 6,4x10x0,7	-	-	-	-	GU14217901	5	
8	Plate	-	-	-	-	GU19235800	1	
9	Screw	-	-	-	-	GU98054314	2	
10	Gasket	-	-	-	-	GU19200300	1	
11	Sensor	-	-	-	-	GU19207220	1	
12	Gasket 8,25x15x1	-	-	-	-	GU12154200	1	
13	Screw M12x1,25	-	-	-	-	GU19237800	1	
14	Low nut M12x1,25	-	-	-	-	GU92602512	1	
15	Gasket	-	-	-	-	GU19201120	1	
16	Locating dowel	-	-	-	-	GU61002100	2	
17	Transmission cage	-	-	-	-	GU19200201	1	
18	Screw M6X30	-	-	-	-	GU98620330	7	
19	Screw M8X35	-	-	-	-	GU98620435	4	
20	Pawl	-	-	-	-	GU55234700	1	
21	Lever return spring	-	-	-	-	GU94321067	1	
22	Breather plug	-	-	-	-	GU19206501	1	
23	Gasket	-	-	-	-	GU10528900	2	
24	Oil plug	-	-	-	-	GU12022600	1	
25	O-ring 20,24X2,62	-	-	-	-	GU90706203	1	
26	Oil level plug	-	-	-	-	GU95980214	1	
27	Locating dowel	-	-	-	-	GU61002100	2	
28	Plug	-	-	-	-	GU19204100	1	
29	Oil seal	-	-	-	-	GU90401832	1	
30	Ball bearing 20x42x12	-	-	-	-	GU92201120	1	
31	Gear box assy	-	-	-	V50	GU19991550	1	